




 CHIMELLA.COM/VIDEOS

WE KNOW YOU'RE EXCITED

But it's a CHIMELLA®... Not a simple umbrella.

For step-by-step videos visit

CHIMELLA.COM/VIDEOS



BEFORE YOU BEGIN

READ THESE INSTRUCTIONS



HOW TO INSTALL YOUR CHIMELLA



HOW TO REMOVE YOUR CHIMELLA



DO'S AND DONT'S

1. If your Chimella slips down the chimney, add tension to the canopy by repeating steps 4 and 5.
2. Don't press the open/close button when reloading the Chimella (step 8) as it breaks the spring.
3. Don't push an open Chimella up a chimney. This will snap the ribs and flip the canopy.
4. Don't grip the display handle when you twist your Chimella (step 3).
5. Don't hold the display handle when reloading your Chimella.
6. Don't fire your Chimella directly at a wall.